

VATSIM Germany GPS / FMS RNAV ARRIVAL CHART

Hamburg
EDDH

Transition Altitude: 5000 ft.

ATIS 123.120

Bremen Radder
127.670
134.250

Director 118.200
Tower 126.850

Transition to Final Approach
RWY 15

- REMARK
1. Use of transitions only when cleared by ATC.
 2. On downwind expect vectors to final.
 3. Speed restrictions on transition (even without profile) are always mandatory, unless cancelled by ATC.

