


FIS
LANGEN INFORMATION
119.150

EGELSBACH APRON/VORFELD
121.730 En/Ge

EGELSBACH INFO
118.405 En/Ge (25 NM 4000 ft GND)

Berichtigung: EGELSBACH INFO/VORFELD (8.33 KHz) Hinder- nisse, Modell-/Drohnenfluggel.
Correction: EGELSBACH INFO/APRON (8.33 KHz), obstacles, model/drone flying sites.



Koordinate Beginn Anflug und Ende Abflug/
Start of approach and end of departure coordinate

TANGO	N 50° 0,3' E 008° 48,8'
ECHO	N 49° 57,1' E 008° 50,2'
KILO	N 49° 52,6' E 008° 43,4'
DELTA	N 49° 52,2' E 008° 36,1'
YANKEE*	N 49° 58,2' E 008° 51,4'

* nur/only Jets, Turboprops