Only for simulation purposes!

Kassel-Calden (EDVK) Quickview Procedures

		Radio Stations	i	
	Ground	Tower	Arrival	Area Control
Main	EDVK_GND AS1	EDVK_TWR AS1		EDWW_S_CTR APC
Main	Kassel Ground	Kassel Tower		Bremen Radar
Station	121,905	118,105		126,650
				EDWW_W_CTR APC
				Bremen Radar
Secondary				123,925
Station				EDWW_CTR ACC
				Bremen Radar
				124,175

Runway Information							
Runway	Bearing	TORA		ILS	ILS CAT	Other APCH	Missed Approach
09	95°	2500m	IKSE	108,10		LOC ; RNP	4000ft ; WRB
27	275°	250011	IKSW	109,30	III	LOC, KNP	

CID	EDVK		
SID	27	09	
ELNAT	4N	1M	
EMBAD	2N	1M	
XAROL	2N	1M	
WRB Warburg	9N	2M	
LUXUX	2N	1M	
WERRA	7N	1M	
Initial Climb 5000 ft			
Initial Climb 4000 ft			

Squawks		
Range	Destination	
1101 – 1137	D F G H LE LI LM LS LP LX EDNY LFSB S	
1330 – 1377	B C EB ED EG EH EI EL LF K M P T	
5050 - 5077	EDDK EDDL EDLW EDLV	
6401 – 6437	BK EP LA LB LC LD LG LH LJ LK LL LO LQ LR LT LU LW LY LZ O R V Z	
7260 – 7277	BG BI EE EF EK EN ES EY U	
7750 – 7775	EDWW	

	Control Zone
CTR	D (HX) 2700 ft

	SID Restrictions
WRB	Not to be used during actvity of
LUXUX	Night Low Flying System!

Low Visibilty Operations		
CAT II	RVR ≤ 600m or	
CATI	BKN < 200ft	
CAT III	RVR ≤ 325m	
ATIS	Low Visbility procedures CAT II/	
	III in operation	

Transition Level		
QNH	TRL	
≥ 1051	50	
1014 – 1051	60	
0979 – 1013	70	
≤ 0978	80	
TA 5000ft		

Kassel-Calden (EDDV) Quickview Explanations

Revisions

1805 Initial release

04.02.19 Corrected TWR and GND frequency (effective 28. FEB 2019!)

General

Header colors always have the same scheme among all quickviews: Orange for departure procedures; blue for arrival procedures; green for enroute or local procedures (depending if the quickview is a center or an aerodrome quickview) and yellow for general information.

Be advised that information might be omitted for tactical reasons (quickviews do have limited space). **Quickviews are no replacement for reading the local procedures thoroughly!**

Squawks and SID restrictions

Squawk ranges for specific destinations are given here. Most of the time, only the country code is given here. For example if the flight has destination LEPA, the squawk range where "LE" is listed under Destination is used. Sometimes also FIR code is given here.

SID restrictions are mostly self-explanatory. ZZZZ▼ applies for flights with destination ZZZZ and ZZZZ▲ applies for flight with departure ZZZZ.